



# KALAMAZOO INDUSTRIES

## S4SWB 4" X 36" BELT SANDER

### PARTS LIST



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	050-048	BASE FOR S4SWB	1
2	486-011	1/2HP, 1PH, 1725RPM, 115/230 FOR DS10, 2FSM-1725, S4S-1725, S4SWB	1
3	291-002	CAST IRON FRAME WITH PLATEN FOR S4, S4S, DS10-4	1
4	SHCA037012	3/8-16 X 3/4 SHCS	4
5	560-005	PULLEY, DRIVE (ALUMINUM) FOR S4, S4S, S460D	1
6	700-001	YOKE SHAFT FOR S4 SANDER	1
7	960-002	YOKE FOR S4 SANDER	1
8	EERR0.5	EERR1/2 1/2" E RETAINING RING	2
9	UFWZ050	1/2 USS F/W Z	1
10	697-010	SPRING, TENSION FOR S4 SANDERS	1
11	HHC5031020	5/16-18 X 1-1/4 HCS GR 5 Z	1
12	FHN5031	5/16-18 FHN GR5 ZINC	1
13	697-011	TRACKING SPRING FOR S4	1
14	CRMZ010024	10-24 X 1-1/2 COMBO ROUND M/S Z	1
15	129-008	CAM FOR S4 TENSION SHAFT	1
16	RUDZ007008	#7 X 1/2 RD U-DRIVE SCREW Z	1
17	701-008	SPINDLE, IDLER FOR S4, S460 SANDERS	1
18	560-006	IDLER PULLEY S4 W BEARINGS FOR S4S AND S460	1
19	123-003	COLLAR FOR S4	1
20	SSKA010004	10-24 X 1/4 SOC SET KNURL PT	2
21	SSKA025006	1/4-20 X 3/8 SOC SET KNURL PT.	1
22	486-050	SUBMERSIBLE PUMP FOR KVF3 S4SWB1P939-0	1
23	BF22	BF22 HOSE BARB 1/4H X 1/4 FP	1
24	050-048A	S4SWB LOWER GUARD ASSEMBLY	1
25	050-048WORKTABLE	WORK TABLE FOR S4SWB	1
26	FSCA025016	1/4-20 X 1 FSHCS	2
27	UFWZ025	1/4 USS F/W Z	6
28	SLWZ025	1/4 SPLIT L/W Z	12
29	FHN5025	1/4-20 FHN GR5 Z	10
30	050-048B	S4SWB UPPER GUARD ASSEMBLY	1
31	HHC5025008	1/4-20 X 1/2 HCS GR5 Z	10
32	050-048-G	TOP DECK ACCESS PLATE FOR S4SWB BASE	1
33	HHC5025012	1/4-20 X 3/4 HCS GR5 Z	4
34	S35BZ0	S35BZ0 MINIATURE BALL VALVE 1/4 M X F	1
35	W05465	W05465 AIR BRAKE BULKHEAD COUPLING 1/4	1
36	TB3703	TB 3703 1 X 1/2 REDUCING WASHER	1
37	BN22	BN22 DX HOSE BARB 1/4H X 1/4 MNPT	1
38	050-048DOOR	S4SWB DOOR	1
39	REDIHD41	R-DOT IHD4-1 1G RT BOX W/4 1/2" HUBS	1
40	TB2920	TB 2920 1/2" .125-.375 CORD CONNECTOR	4
41	710-007	ON/OFF TOGGLE SWITCH FOR SMALL SANDERS AND GRINDERS 1185-Q/20B	1
42	710-008	ON/OFF PLATE 1132	1
43	710-056	TOGGLE SWITCH COVER 12-B BLACK FLEX-STANDARD	1